


SS - 64 To Icom IC-25A/E Mobile



Notes

This hookup sheet can also be used for the IC-45A/E (UHF) model. If you want the reverse burst function, follow the directions on the SS-64 instruction sheet to install into your radio's push-to-talk.

** The Orange wire must be grounded to encode tone if jumper JP-1 is out